

# Cable Marker



## KS 20

Marking machine for embossing hot plastic insulated wires or cables

Stamping at speeds up to 300 m/minute



### Applications

- Stamping hot insulation within the production line immediately after the extruder.
- Stamping at speeds up to 300 m/minute, gravure printing up to 150 m/min.
- Processing cables 1.5 to 40 mm in diameter.

### Standard Configuration

- Frame with support column and height adjustment crank mechanism.
- Marking unit with one marking station and guide rollers.
- Conversion kit for gravure printing.
- Complete accessories kit without stamping/printing discs.
- Custom type discs are available separately.

### Features

- Recessed or raised lettering.
- Convertible to gravure printing.



**MEDEK & SCHÖRNER GMBH**  
Cable Marking Systems

Kuefsteingasse 32 · A-1142 Vienna/Austria (Europe) · Phone 43-1-982 32 04-0  
Fax 43-1-982 72 96 · e-mail: m+s@medek.at · www.medek.at